MGI64 Upgrade Procedure (Simple Look)

1. Connect SIO Cable

   SET : 36800-8-none-1-none

2. Login MGI64 Board.

   * Bootrom Mode: id – mgi, pwd – mgi

   * Program Mode: id – mgi, pwd – mgi1234

   * Telnet Mode: id – mgi, pwd – mgi12345

3. Run Config Command.

   * Input "allset" command and follow the command.

4. Reboot
--
MGI64 Card use the tftp upgrade method.
so, prepare one computer for tftp server, and SIO Cable.

When you configure the tftp server IP address, and MGI64 Card IP address,
Restart the MGI64 Card.   It make automatically upgrade MGI64 new S/W.

   1.   Make "MGI64" New Directory.

2. Copy MGI64 S/W

3. First Install tftp Server program.

4. Configure tftp Server like below.

   File -> Configure

* This is Tftp Root Directory
* MGI64 directory will be show.

5. Check Security Option

6. Connect MGI64 with SIO cable

Before the digit 0, press 'enter key'

Id: mgi

Pwd: mgi

```
테라텀 - COM1 VT
파일(F)  편집(E)  설정(S)  제어(O)  Window  도움말(H)
MGI64:165.213.66.22>

------------------------------------------------------------
 If you want to set Network Parameter,
         Press Enter Key and Log In Network Setting Mode!!!
------------------------------------------------------------
count : 3
login:
Password:
MGI64:165.213.66.22>
MGI64:165.213.66.22>
MGI64:165.213.66.22> allset


MGI64 Network Parameter Change
(If you dont want to modify, Press Enter Key
============================================================
Current MGI64 IP Address:165.213.66.22
New     MGI64 IP Address:165.213.66.22
Current MGI64 SubnetMask:255.255.255.0
New     MGI64 SubnetMask:255.255.255.0
Current MGI64 Gateway:165.213.66.1
New     MGI64 Gateway:165.213.66.1
Current Package Server IP Address:165.213.89.128
New     Package Server IP Address:165.213.89.128
============================================================



      <<<< MGI64 network information >>>>
============================================================
 MAC     Address : 00:00:F0:C3:78:23:
 IP      Address : 165.213.66.22
 Subnet  Mask    : 255.255.255.0
 Gateway Address : 165.213.66.1
 Server  Address : 165.213.89.128
============================================================
value = 50 = 0x32 = '2'
MGI64:165.213.66.22> _
```

Input "allset" command

Tftp Server IP address

7. After then, reboot, MGI64 Card reload the S/W imge. And save it.